



INSTALLATION INSTRUCTIONS

SMART RV Anchor Pods can be mounted to various surfaces with the included fasteners:

Mount to bare studs or sheetrocked wall (in your garage)

or

Mount to RV exterior (must be smooth wall)

or

Mount to RV interior wall

Step 1

In all cases, avoid any obstructions and locate studs (or RV floorline/framing) with a stud finder.

- For any RV wall installation, turn off all utilities.

If necessary, prepare your Pods. Pods have closed holes at the center top and bottom, you will need to drill these out with a 3/8" drill bit. No preparation will be necessary if you will be mounting your Pods at your RV floorline and using the Left and Right holes only.

Step 2

Choose Pod's mounting location and mark horizontal mounting line.

- For RV exterior, this line will fall within the framing for the RV floor.
- For Garage, measure 36-40" from the ground for Pod mounting. Mark location on the wall with a pencil.
- Single-pod accessories (ie: LCD Post, Trash Bin, and Universal Hook) can be mounted at any convenient height, just be sure to mount to a stud.
- For 2-pod accessories, mark a horizontal, level mounting line using a straight edge or chalk line.

Step 3

Using the provided template, mark the first Pod location with a cross hairs--marking a vertical line along your horizontal line for the center of the pod location. Tape the template to the mounting spot, and mark the 2 starter holes, center Top and Bottom (vertical stud installations) or Left and Right (RV floorline installations) with a center punch.

- Double-check template before using by placing Pod over template. The bullseyes must be in the center of the horizontal and vertical holes.
- When mounting to a Garage or any wood stud, only the two (center Top and Bottom) holes will be used with the #10 Screws.
- When mounting to an RV exterior with wood or aluminum studs the two vertical holes will be used with #8 anchor fasteners plus Adhesive.
- When mounting to an RV exterior at the floorline/framing, the two horizontal (Left and Right) holes will be used with #8 anchor fasteners plus Adhesive.

Step 4

For Garage/Wood Stud:

Drill pilot holes using a 1/8" drill bit.

* * * * *

For RV Exterior:

Drill the 2 holes using a 3/16" drill bit.
Drill holes to a Depth of 1" to accommodate #8 anchor.

Tip: We recommend applying masking tape to the drill bit to prevent drilling too deep.

Insert #8 anchors (plastic piece only).
Prepare the mounting area by lightly sanding the fiberglass between the drilled holes.
Clean the surface of the wall.

Step 5

For Garage/Wood Stud:

Attach Pod using the wood screws.

* * * * *

For RV Exterior:

Apply adhesive onto the backside of the Pod. Filling gaps is recommended, but avoid overfilling.
Lining up holes, apply Pod to RV wall. Wipe off any excess adhesive with a paper towel.
Install #8 screws.

Allow Pod adhesive to cure completely.

The SMART RV accessories can now be safely mounted.

When Pods are not in use, you can cover the pods with the Pod covers included.

- Tip: Covers are easily removed by squeezing together from both ends.

* * * * *

SMART RV GUIDELINES & PRECAUTIONS

When using SMART RV Pods and Accessories, the user must understand the precautions. The points listed below will assist you in using the SMART RV system and will encourage safety.

Please review the instructions and warranty information carefully. Proper assembly and installation are the end user's responsibility and beyond the manufacturer's control.

- Remove your SMART RV accessories when they are not in use and before moving or operating the vehicle.
- When installing or attaching SMART RV accessories, be aware of existing heat sources, gas lines, water lines, electrical lines, and other potential hazards installed by the manufacturer.
- Do not use SMART RV mounting points and accessories for purposes other than those for which they were designed. Do not exceed their carrying capacity. Failure to follow these guidelines or the product's instructions will void the warranty.